

# TTR110 With TBW1826



**Installation notes** – We recommend the use of a Outerwear like [TBW1494](#) for extra filter protection.

The throttle cable should exit the left side of the bike between the split frame (Do not route it under the frame or between the gas tank and frame)

